



DESCALER FOR KITCHEN APPLIANCES



PRODUCT DESCRIPTION

Professional cleaner for the descaling of dishwashers, coffee machines, drinks vending machines, pipes and kitchen equipment.

FEATURES & BENEFITS

- For descaling according to machine manuals.
- Helps the economic and correct descaling process.
- To be used regularly according to machine manuals.
- Extends the life of your appliances.

USAGE

Dishwasher – Stop the automatic dispensing of dishwasher liquid soap. Depending on the quantity of lime scale, add 100-200ml per liter and run 2 empty wash cycles. Then allow the dishwasher to drain and switch on the automatic liquid soap dispenser. Other kitchen equipment – Depending on the quantity of lime scale, add 100-200ml per litre and run the machine for 15 minutes or follow the machine specific descaling manual. Then rinse with clean water.

STORAGE

Keep package well closed, and store under cool but frost-free temperatures.

RECYCLING

Empty pack can be fully recycled when rinsed with water. Dispose of through the correct channel



AVAILABLE

Article code	Box content	Packaging	Pallet-quantity
714-0001-002	12 x 1 liter	Handle Bottle	40 cartons

CERTIFICATES



COMPOSITION

Contains : Lactic Acid / CAS: 79-33-4

UFI CODE

5AY1-501N-000E-0A0U

PH

PH VALUE														
0	1	2	3	4	5	6	7	8	9	10	11	12	13	14